

Spare Parts List - LP301A-0056

ITEM	PART	DESCRIPTION	QTY	ITEM	PART	DESCRIPTION	QTY
1	07759	Crankcase	1	36	04842	Grooved Ring	3
2	13000	Oil Filler Plug Assy.	1	36A	04380	Support Disc	3
3	05940	Cover Plate	1	37	13240	Seal Case	3
3A	07223-0100	Spring Ring	2	38	07140-0006	O-Ring, Aflas	3
3B	05051	Hexagon Screw	2	38A	04835	Support Ring	3
4	06085	Crankcase Cover	1	39	12055-0006	O-Ring, Aflas	3
5	07104	O-ring, Crankcase Cover	1	39A	04837	Support Ring for 39	3
6	05943	Oil Sight Glass w/Gasket	1	40	07685	Spiral Ring	6
8	06086	Oil Dipstick Assy.	1	40A	04381	Guide Ring	3
9	01009	O-Ring, (For Dipstick)	1	40B	04382	Support Disc	3
10	01010	Cylinder Screw	4	40C	07718	Support Ring	3
11	01011-0400	Spring Ring	5	41	07338	Pressure Spring	3
12	07109	Plug, 1/2" BSP	1	43	13040	Valve Casing	1
13	07182	Gasket	1	44A	07150-0006	O-Ring, Aflas	9
14	07111	Bearing Cover	2	44B	04834	Support Ring for O-Ring	3
15	07112	Radial Shaft Seal	2	45	06078	Compression Spring	3
16	07113	O-Ring for Bearing Cover	2	46	07060	Valve Assy., Complete	6
17	07114	Hexagon Screw	8	46A	07064	Valve Seat	6
20	07116	Taper Roller Bearing	2	46B	07063	Valve Plate	6
20A	07117	Fitting Disc	1-3	46C	07062-0100	Valve Spring	6
20B	13001	Fitting Disc	1-3	46D	07066	Spacer Pipe	6
21	05376	Shaft Protector	1	48	06077	Plug	3
21A	05377	Shaft Guard Holder	1	49	07157	Stud bolt	8
22	13242	Crankshaft	1	49A	07158	Hexagon Nut	8
23	13243	Key	1	49B	07159	Disc	8
24	13340	Connecting Rod Assy.	3	50	12250	Plug, 1/2" BSP, S.S.	1
25	13341	Crosshead Assy.	3	50A	06807	Steel Ring	1
28	13232	Crosshead Pin	3	52	13020	Disc for Crankshaft	1
29A	07125	Centering Sleeve	3	53	04561	Hexagon Screw	1
29B	07127	Plunger Pipe	3	54	13044	Plug, 1" BSP	1
29C	13031	Tensioning Screw	3	55	04836	Plug, 1-1/4" BSP w/1/8" BSP port	1
29D	07755	Copper Ring	3	60	04583	Connector	1
30	07779	Oil Scraper	3	61	04838	Y-Connector, 1/8" BSP	2
31	07133	Oil Seal	3	62	04839	L-Joint, 1/8" BSP	1
35	04833	Seal Sleeve	3	64	04786	Hose, Teflon	1

Repair Kits

Plunger Packing Kit

09459-0056

For pumps manufactured on or after 4/96

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
36	04842	Grooved Ring	3
38	07140-0006	O-Ring	3
38A	04835	Support Ring	3
39	12055-0006	O-Ring	3
39A	04837	Support Ring	3
40	07685	Spiral Ring	6
40A	04381	Guide Ring	3
40C	07718	Sleeve, Teflon	3

Valve Kits

09196-0006

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
44A	07150-0006	O-Ring	6
44B	04834	Support Ring	3
46A	07064	Valve Seat	3
46B	07063	Valve Plate	3
46C	07062-0100	Valve Spring	3

Oil Seal Kit

09577

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
31	07133	Oil Seal	3