

Parts List - BP8076

<u>Item</u>	<u>Part</u>	<u>Description</u>	<u>Qty</u>	<u>Item</u>	<u>Part</u>	<u>Description</u>	<u>Qty</u>
1	05380	Crankcase	1	41	03599	Guide Ring	3
2	06893	Oil Filler Plug Assy with Vent	1	42	03568	Spiral Ring	6
5	22929	Copper Washer	2	43	03600	Spacer Pipe	3
6	12256	Plug	1	44	03601	Lubrication Ring	3
7	05656	Plug, 3/8" BSP	1	46	03602	Pressure Sleeve	3
8	01008	Oil Dipstick Assembly	1	49	05072	Stud Bolt	8
9	01009	O-Ring	1	49A	05073	Hexagon Nut	8
12	07109	Plug, 1/2" BSP	2	50	03603	Valve Casing	1
13	06272	Seal	2	50A	13162	Centering Stud	4
14	05036	Bearing Cover, Closed	1	50B	03604	Discharge Valve Casing	1
14A	03597	Bearing Cover, Open	1	51	03613	Valve Assembly (51A-51J)	6
15	05112	Radial Shaft Seal	1	51A	03605	Spring Tension Cap	6
16	05037	O-Ring	2	51B	03606	Guide Bush	6
17	05038	Hexagon Socket Screw	16	51C	05080	Valve Spring	6
18	05039	Spring Ring	16	51D	03607	Valve Plate	6
21	05044	Tapered Roller Bearing	2	51E	03608	Gasket for Valve	6
21A	05042	Fitting Disc	1-5	51F	03609	Valve Seat	6
21B	05043	Fitting Disc	1-5	51G	03610	Guide Ring	6
22	05299	Crankshaft	1	51H	03434	O-Ring	6
23	05104	Fitting Key	1	51J	07193	O-Ring	6
24	05047	Connecting Rod Assembly	3	56	03576	Discharge Valve Adaptor	3
25	05048	Crosshead c/w Plunger	3	56A	04955	O-Ring	3
28	05049	Crosshead Pin	3	56B	13156	O-Ring	3
30	05052	Cover Plate	1	57	05279	Pressure Spring	3
30A	07225-0100	Hexagon Screw	5	57A	07210-0100	Pressure Spring	3
30B	13136	Grommet	5	58	05087	Hexagon Socket Screw	12
30C	05053	Washer	5	59	07109	Plug 1/2" BSP	2
31	07623	Eye Bolt	3	59A	06272	Copper Seal	2
32	05058	Radial Shaft Seal	3	60	13322	Plug 1-1/2" BSP	1
32A	03118	Scraper	3	61	05088	Plug 3" BSP	1
33	03119	Seal Retainer	3	68	03611	Mounting Aid for Valve (not shown)	1
33A	05056	O-Ring	3	78	03612	Oil Cooler Assembly	1
33B	05054	Clip Ring	3	K1	05026	Cooling Vane Plate	1
33C	05059	Fitting Disc	3	K2	05027	Seal for Gear Cover	2
36A	04934	Plunger Pipe Cover	3	K3	05028	Gear Cover	1
36B	03561	Plunger Pipe	3	K4	05029	Hexagon Head Countersunk Screw	4
36C	05062	Tension Screw	3	K5	07381	Hexagon Socket Screw	8
36D	07665	Copper Washer	3	K6	08041	Washer	8
36E	06900	Centering Sleeve	3	K8	06272	Copper Seal	4
38	03563	Seal Case	3	K9	07109	Plug, 1/2" BSP	2
38A	03564	O-Ring	6	K10	05031	Connecting Branch	2
39	03598	Seal Sleeve	3	K18	04158	Hexagon Socket Screw	4
39A	05066	O-Ring	3	K19	05053	Washer	4
39B	04374	Lubrication Nipple	3				
40	03566	Support Ring	3				

Repair Kits - BP8076

Plunger Packing Kits - #09863

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
38A	03564	O-Ring	6
39A	05066	O-Ring	3
40	03566	Support Ring	3
41	03599	Guide Ring	3
42	03568	Spiral Ring	6

Valve Repair Kit - #09864

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
51	03613	Valve Assembly	6
56A	04955	O-Ring	3
56B	13156	O-Ring	3

Oil Seal Kit - #09584A

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
32	05058	Radial Shaft Seal	3
32A	03118	Scraper	3
33A	05056	O-Ring	3