

GP6124-4000 PARTS LIST

ITEM	PART	DESCRIPTION	QTY.	ITEM	PART	DESCRIPTION	QTY.
1	13200	Crankcase	1	38A	07721	O-Ring	3
2	13000	Oil Filler Plug Assembly	1	39	05880	Seal Case	3
4	13201	Crankcase Cover	1	39A	12055	O-Ring	3
5	13202	O-Ring, Crankcase Cover	1	39B	07693	Support Ring	3
8	13203	Oil Dip Stick	1	39C	07354	O-Ring	3
9	01009	O-Ring, Dip Stick	1	39D	12056	Support Ring	3
10	22706	Hexagon Screw	12	40	07173	Seal Sleeve	3
11	06725	Spring Washer	12	41	05883	Seal Case	3
12	07109	Drain Plug	5	42	07685	Support Ring	6
13	06272	Gasket, Drain Plug	2	43	07718	Support Ring	6
14	12549	Bearing Cover	2	44	06956	Guide Ring	3
15	07877	Radial Shaft Seal	2	45	13049	Grooved Ring	3
16	08055	O-Ring	2	45A	05884	Drip Return Support Disc	3
20	13206	Taper Roller Bearing	2	45B	05885	Clip Ring	3
20A	13207	Fitting Disc (Shim)	1-5	46	04786	Hose	1
21	05881	Shaft Guard Mount	1	47	04785	Push-In Fitting	6
21A	05646	Shaft Guard	1	49	13159	Stud Bolt	8
22	06895	Crankshaft	1	49A	06958	Nut	8
23	08213	Key	1	49C	13162	Centering Stud	2
24	06896	Connecting Rod Assembly	3	50	03682	Valve Casing	1
25	12550	Crosshead Assembly	3	51	08286	Valve Assembly, 51A-E	6
28	06898	Crosshead Pin	3	51A	07064-0100	Valve Seat	6
30	13214	Cover Plate	1	51B	13130	Valve Plate	6
30A	07225-0100	Hexagon Screw	4	51C	07062-0100	Valve Spring	6
30B	13136	Grommet	4	51D	05472	Spacer Pipe	6
30C	08280	Washer	4	51E	05473	Valve Spring Guide	6
31	07623	Eye Bolt	1	56	06077	Tensioning Plug	3
32	06118	Radial Shaft Seal	3	56A	07150	O-Ring	9
33	13216-0100	Seal Retainer	3	56B	06266	Support Ring	3
33A	07721	O-Ring	3	56C	06078	Spring	3
33B	13217	Circlip	3	59	06807	Steel Ring	3
33C	12551	Fitting Disc	3	60	13150-0100	Plug, 3/4" BSP	1
34	13218	Flinger	3	61	13151	Plug, 1-1/4" BSP	1
37	13397	Plunger Pipe	3	66	13362	Disc, Crankshaft	1
38	05882	Seal Sleeve	3	67	13358	Inner Hexagon Screw	1

GP6124-4000 REPAIR KITS

Plunger Packing Kit

09872

Item	Part #	Description	Qty
38A	07721	O-Ring	3
39A	12055	O-Ring	3
39B	07693	Support Ring	3
39C	07354	O-Ring	3
39D	12056	Support Ring	3
42	07685	Support Ring	6
44	06956	Guide Ring	3
45	13049	Grooved Ring	3
46	04786	Hose	1

Valve Assembly Kits

09874

Item	Part #	Description	Qty
51A	07064-0100	Valve Seat	6
51B	13130	Valve Plate	6
51C	07062-0100	Valve Spring	6
51D	05472	Spacer Pipe	6
51E	05473	Valve Spring Guide	6
56A	07150	O-Ring	9
56B	06266	Support Ring	3

Oil Seal Kit

09870

Item	Part #	Description	Qty
32	06118	Radial Shaft Seal	3
33A	07721	O-Ring	3
33B	13217	Circlip	3