

GP6132 SPARE PARTS LIST

<u>ITEM</u>	<u>PART</u>	<u>DESCRIPTION</u>	<u>QTY.</u>	<u>ITEM</u>	<u>PART</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	13200	Crankcase	1	36A	07125	Centering Sleeve	3
2	13000	Oil Filler Plug Assembly	1	37	13022	Plunger Pipe	3
4	13201	Crankcase Cover	1	38	13031	Tensioning Screw	3
5	13202	O-Ring for 4	1	39	07755	Copper Ring	3
8	13203	Oil Dipstick Assembly	1	40	05192	Seal Sleeve	3
9	01009	O-Ring for 8	1	41	13222	Seal Case	3
10	13133	Hexagon Screw	12	41A	07721	O-Ring for 41	3
11	06725	Spring Washer	12	41B	13223	Support Ring for 41A	3
12	07109	Drain Plug	3	41C	12055	O-Ring for 41	3
13	06272	Seal for 12	2	41D	07693	Support Ring for 41C	3
14	12549	Bearing Cover	2	42	07173	Tension Spring	3
15	07877	Radial Shaft Seal	2	43	05176	Sleeve Support Ring	3
16	08055	O-Ring for 14	2	44	06096	Sleeve	6
20	13206	Taper Roller Bearing	2	44A	05174	Pressure Ring	3
20A	13207	Fitting Disc	1-5	45	13360	Leakage Seal	3
21	05881	Shaft Guard Mount	1	46	05169	Threaded Pipe	3
21A	05646	Shaft Protector	1	49	13159	Stud Bolt	8
22	06895	Crankshaft	1	49A	13160	Nut	8
23	08213	Fitting Key	1	49C	13162	Centring Stud	2
24	06896	Connecting Rod Assembly	3	50	05191	Valve Casing	1
25	06897	Crosshead Assembly	3	51	03676	Valve Assembly (51A-E)	6
28	06898	Crosshead Pin	3	51A	12564	Valve Seat	6
30	13214	Cover Plate	1	51B	03677	Valve Plate	6
30A	07225-0100	Hexagon Screw	4	51C	03673	Valve Spring	6
30B	13136	Grommet	4	51D	03674	Spacer Pipe	6
30C	08280	Disc	4	51E	03675	Valve Spring Guide	6
31	07623	Eye Bolt	1	52	05166	O-Ring for 51	6
32	06118	Radial Shaft Seal	3	56	05171	Plug	3
33	13216	Seal Retainer	3	57	05167	O-Ring for 56	3
33A	07721	O-Ring for 33	3	59	07661	Copper Seal for 12	1
33B	13217-0100	Circlip for 33	3	60	13151	Plug, 1-1/4" BSP	1
33C	12551	Fitting Disc (not shown)	3	61	13171	Plug, 2-1/2" BSP	1
34	13218	Oil Scraper	3	66	13362	Disc for Crankshaft	1
36	13219	Plunger Connection	3	67	13358	Hexagon Screw	1

GP6132 REPAIR KITS

Plunger Packing Kit # 09871

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
41A	07721	O-Ring	3
41B	13223	Support ring	3
41C	12055	O-Ring	3
41D	07693	Support Ring	3
44	06096	Sleeve	6
45	13360	Leakage Seal	3

Valve Assembly Kits #09869

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
51A	12564	Valve Seat	6
51B	03677	Valve Plate	6
51C	03673	Valve Spring	6
51E	03675	Valve Spring Guide	6
52	05166	O-Ring	6
57	05167	O-Ring	3

Oil Seal Kit # 09870

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
32	06118	Radial Shaft Seal	3
33A	07721	O-Ring	3
33B	13217-0100	Circlip	3