

GP7128 PARTS LIST

ITEM	PART	DESCRIPTION	QTY.	ITEM	PART	DESCRIPTION	QTY.
1	05769	Crankcase	1	38C	07354	O-Ring for 39	3
1A	05525	Head for Oil Dipstick	1	38D	12056	Support Ring for 38C	3
1B	01009	O-Ring, Dipstick	1	39	06426	Seal Sleeve	3
2	13000	Oil Filler Plug Assembly	1	39A	13228	Grooved Ring	3
4	07601	Crankcase Cover	1	41	13417	Pressure Ring	3
5	05798	Seal for Cover	1	42	13369	V-Sleeve	6
8	07603	Oil Dip Stick Assembly	1	43	06862	Sleeve Support Ring	3
9	01009	O-Ring, Dip Stick	1	43A	05355	Spacer Ring	3
10	22706	Inner Hexagon Screw	8	45	07173	Tension Spring	3
11	06725	Spring Washer	8	49	13159	Stud Bolt	8
12	07109	Drain Plug	9	49A	13160	Hexagon Nut	8
13	06272	Copper Seal	9	50	06798	Valve Casing	1
14	05770	Bearing Cover	2	50A	13162	Cylinder Stud	2
14A	12204	O-Ring	8	51	04727	Inlet Valve Assembly (51B-F)	3
15	05771	Radial Shaft Seal	2	51B	05193	O-Ring	3
16	05772	O-Ring, Bearing cover	2	51C	04725	Inlet Valve Seat	3
17	05642	Inner Hexagon Screw	8	51D	13130	Valve Plate	3
18	05039	Spring Washer	8	51E	07062-0100	Valve Spring	3
20	05773	Taper Roller Bearing	2	51F	13147	Spacer Pipe	3
20A	05774	Fitting Disc (Shim)	1-8	52	04728	Discharge Valve Assembly (52B-F)	3
21	05645	Holder for Shaft Protector	1	52B	05193	O-Ring	3
21A	05646	Shaft Protector	1	52C	04726	Discharge Valve Seat	3
22	05575	Crankshaft	1	52D	13130	Valve Plate	3
23	07614	Key	1	52E	07062-0100	Valve Spring	3
24	05777	Connecting Rod Assembly	3	52F	13147	Spacer Pipe	3
25	05778	Crosshead Assembly	3	57	06078	Compression Spring	3
28	05779	Crosshead Pin	3	58	07699	Plug	3
30	07619	Cover Plate	1	58A	07700	O-Ring	3
30A	07225-0100	Hexagon Screw	8	58B	07693	Support Ring	3
30B	13136	Grommet	4	58C	07702	Hexagon Screw	12
30C	08280	Disc	8	60	04576	Plug, 3/4" NPT	1
30D	13154	Cover	1	61	12251	Plug, 1-1/4" NPT	1
31	07623	Eye Bolt	1	66	13362	Disc for Crankshaft	1
32	07624	Radial Shaft Seal	3	67	13358	Hexagon Screw	1
33	07626	Seal Retainer	3		07662	Tool for valve assembly	
33A	07627	O-Ring for 33	3		17212	Crankcase Assembly (1-34/49/49A/50A/66/67)	
33B	07628	Circlip for 33	3		04671	Manifold Assembly (50-61 w/out 50A)	
33C	07249	Shim	3		03046	Plunger Replacement Kit (36-45)	
34	13137	Flinger	3				
36	06427	Plunger	3				
38	05354	Seal Case	3				
38A	12055	O-Ring, Seal Case	3				
38B	07693	Support Ring for 38A	3				

GP7128 Pump Repair Kits

Plunger Packing Kit - 09464

Item	Part #	Description	Qty.
38A	12055	O-Ring, Seal Case	3
38B	07693	Support Ring	3
38C	07354	O-Ring	3
38D	12056	Support Ring	3
39A	13228	Grooved Ring	3
42	13369	V-Sleeve	6
43	06862	Sleeve Support Ring	3

Oil Seal Kit # 09221

Item	Part #	Description	Qty.
32	07624	Radial Shaft Seal	3
33A	07627	O-Ring	3

Valve Assembly Kit - #09520

Item	Part #	Description	Qty.
51B	05193	O-Ring	3
51C	04725	Inlet Valve Seat	3
51D	13130	Valve Plate	3
51E	07062-0100	Valve Spring	3
52B	05193	O-Ring	3
52C	04726	Discharge Valve Seat	3
52D	13130	Valve Plate	3
52E	07062-0100	Valve Spring	3
58A	07700	O-Ring	3
58B	07693	Support Ring	3