

Part List - GP8035 Pump

Item	Part	Description	Qty	Item	Part	Description	Qty
1	05380	Crankcase	1	50A	13162	Centering Stud	2
2	06893	Oil Filler Plug Assy. with Vent	1	50B	05836	Discharge Casing	1
5	22929	Seal	2	51	05837	Inlet Valve Assy.	3
6	12256	Plug	1	51A	05595	Spring Tension Cap	3
7	05656	Plug, 3/8" BSP	1	51B	05838	Inlet Valve Seat	3
8	05035	Oil Dipstick Assy	1	51C	05752	Valve Plate	3
9	01009	O-Ring	2	51D	05408	O-Ring	3
12	07109	Plug, 1/2" BSP	2	51E	05450	Valve Spring	3
13	06272	Copper Gasket, 1/2" BSP	2	51F	05596	O-Ring	3
14	05036	Bearing Cover Closed	1	52	05839	Discharge Valve Assy	3
14A	05298	Bearing Cover Open	1	52A	05595	Spring Tension Cap	3
15	05112	Radial Shaft Seal	1	52B	05840	Discharge Valve Seat	3
16	05037	O-Ring	2	52C	05752	Valve Plate	3
17	05038	Hexagon Socket Screw	16	52D	05408	O-Ring	6
18	05039	Spring Ring	16	52E	05450	Valve Spring	3
21	05044	Tapered Roller Bearing	2	52F	05596	O-Ring	3
21A	05042	Fitting Disc	5	56	05409	Discharge Valve Retainer	3
21B	05043	Fitting Disc	5	56A	05408	O-Ring	3
22	05299	Crankshaft	1	57	07173	Tension Spring	6
23	05300	Fitting Key	1	58	05753	Hexagon Socket Screw	12
24	05047	Connecting Rod Assembly	3	59	07109	Plug, 1/2" BSP	3
25	05048	Crosshead c/w Plunger	3	59A	06272	Copper Gasket, 1/2" BSP	3
28	05049	Crosshead Pin	3	60	13044	Plug, 1" BSP	1
29	05051	Hexagon Screw	4	61	05841	Plug, 2" BSP	1
29A	05381	Bracket 1 for Cooling Hose	2	62	05842	Intermediate Casing	1
29B	05383	Hose Shell for Cooling Hose	2	62A	05843	Flat Seal	1
30	05052	Cover Plate	1	62B	05754	Hexagon Socket Screw	4
30A	07225-0100	Hexagon Screw	5	62C	22764	Serrated Pin	4
30B	13136	Grommet	5	62D	05844	Flat Leakage Seal	3
30C	08280	Washer	9	63	05845	Drip Return Joint	2
30D	05050	Splash Cover	1	63A	05757	Leakage Seal	2
31	07623	Eye Bolt	3	63B	05811	Hexagon Socket Screw	4
32	05058	Radial Shaft Seal	3	64	05846	Drip Return Nipple	2
33	05055	Seal Retainer	3	64A	05812	O-Ring	6
33A	05056	O-Ring	3	65	05847	Drip Return Connection	1
33B	05054	Clip Ring	3	65A	05848	Drip Return Plug	1
33C	05059	Fitting Disc	3	66	05303	Disc for Crankshaft	1
34	05060	Oil Shield	3	67	13433	Hexagon Screw	1
34A	05830	Locking Disc	3	79	07662	Tool for Valve	1
36	05743	Plunger Pipe	3				
38	05831	Seal Case	3	78	05849	Oil Cooler	1
38A	05408	O-Ring	6	K1	05026	Cooling Vane Plate	1
39	05832	Seal Sleeve	3	K2	05027	Seal for Gear Cover	2
39A	05056	O-Ring	3	K3	05028	Gear Cover	1
40	05744	Sleeve	3	K4	05029	Hexagon Head Countersunk Screw	8
40A	05745	O-Ring	3				
40B	05746	Pressure Ring	3	K5	07381	Hexagon Socket Screw	8
40C	06584	Clip Ring	3	K6	08041	Washer	6
41	05833	Pressure Ring	3	K7	05741	Connection for Oil Cooler	1
41A	05747	Guide Ring	3	K8	06272	Copper Gasket, 1/2" BSP	6
42	05748	Rope Packing	6	K9	07109	Plug, 1/2" BSP	2
43	05749	Support Disc	3	K10	05031	Connecting Branch	3
44	05751	Support Ring	6	K11	05032	Hose Adaptor	4
45	06098	Tension Spring	3	K12	05033	Tube for Cooler	2
49	05834	Stud Bolt	8	K13	05402	Hose Clamp	4
49A	05073	Hexagon Nut	8	K14	05403	Hose Guard	2
50	05835	Valve Casing	1	K15	05404	Hose Coupling Nut	1
				K16	05405	Flat Gasket for Oil Cooler	4