

## LP470 Parts List

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
1	07759	Crankcase	1	30	07779	Oil Scraper	3
2	13000	Oil Filler Plug Assembly	1	31	07133	Oil Seal	3
3	05940	Cover Plate	1	35	13392	Seal Sleeve	3
3A	07223-0100	Spring Ring	2	37	13393	Seal Case	3
3B	05051	Hexagon Screw	2	38	07140	O-Ring	3
4	06085	Crankcase Cover	1	38A	12055	O-Ring	3
5	07104	O-Ring, Crankcase Cover	1	39	04128	Pressure Ring	3
6	05943	Oil Sightglass with Gasket	1	40	04129	Sleeve, Front	3
8	06086	Oil Dipstick Assembly	1	40A	04130	V-Sleeve, Back	3
9	01009	O-Ring, Dipstick	1	41	04131	Support Ring	3
10	01010	Cylinder Screw	4	42	07338	Pressure Spring	3
11	01011-0400	Spring Ring	5	43	03007	Valve Casing	1
12	07109	Plug, 1/2" BSP	1	44A	07150	O-Ring	9
13	06015	O-Ring	1	44B	06266	Support Ring	3
14	07111	Bearing Cover	2	45	06078	Compression Spring	3
15	07112	Radial Shaft Seal	2	46	08286	Valve Assembly (46A-E)	6
16	07113	O-Ring	2	46A	07064-0100	Valve Seat	6
17	07114	Hexagon Screw	8	46B	13130	Valve Plate	6
20	07116	Taper Roller Bearing	2	46C	07062-0100	Valve Spring	6
20A	07117	Fitting Disc	1-3	46D	05472	Spacer Pipe	6
20B	13001	Fitting Disc	1-3	46E	05473	Valve Spring Guide	6
21	05376	Shaft Protector	1	48	06077	Plug	3
21A	05377	Shaft Guard Holder	1	49	07754	Stud bolt	8
22	13242	Crankshaft	1	49A	07158	Hexagon Nut	8
23	13243	Woodruff Key	1	49B	07159	Disc	8
24	13340	Connecting Rod Assembly	3	52	13020	Disc for Crankshaft	1
25	13244	Crosshead / Plunger Assy.	3	53	06607	Hexagon Screw	1
28	13232	Crosshead Pin	3	54	13044	Plug, 1" BSP	1
29A	07256	Centering Sleeve	3	55	13151	Plug, 1-1/4" BSP	1
29B	04127	Plunger Pipe	3		04165	Crankcase Assembly (1-29A/30/31/49/49A-B/52/53)	
29C	13007	Tensioning Screw	3				
29D	07258	Copper Ring	3		05437	Pumphead Assembly (43-48/50/50A)	

## LP470 Repair Kits

### Plunger Packing Kit - # 09741

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
38	07140	O-Ring	3
38A	12055	O-Ring	3
39	04128	Pressure Ring	3
40	04129	Sleeve, Front	3

### Valve Assembly Kit - # 09742

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
44A	07150	O-Ring	9
44B	06266	Support Ring	3
46	08286	Valve Assembly	6

### Oil Seal Kit - # 09577

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
31	07133	Oil Seal	3