

P200A-5100 SERIES PARTS LIST

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>	<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	08300C	Crankcase	1	17	08442	Wrist Pin	3
2	08301	Dipstick, Except P217-5100	1	19	08356	Oil Seal	3
2	08480	Dipstick, P217-5100 Only	1	20	08444A-0100	Seal Retainer, 316 S.S.	3
3	08302	Crankcase Cover	1	21	08443	O-Ring (-5100)	3
3A	07190-0100	Drain Plug & Gasket	1	21	08443-0001	O-Ring, Viton (-5111)	3
4	08005	O-Ring	1	23	06704	Grooved Seal (-5100)	3
5	08185-0100	Oil Drain Plug with seal	1	23	08087-0010	Grooved Seal, Viton (-5111)	6
6	07188-0100	Screw, 316 S.S.	4	23A	08087	Grooved Seal Ring, Brown (-5100)	3
6A	07223-0100	Spring Washer, 316 S.S.	4	23B	06163	Drip Shield	3
7	08303	Bearing Cover	2	24	07904	Pressure Ring	3
8	08491	Sight Glass	1	25	08445-0100	Weep Return Ring, 316 S.S.	3
9	07193	O-Ring	1	26	06582-5000	Valve Casing	1
10	07225-0100	Screw	8	26A	03469	Valve Assembly (27-30) (except P221/P230-5111)	6
10A	07223-0100	Spring Washer	8	26A	04273	Valve Assembly (27-30) (P221/P230-5111 only)	6
11	08331	Radial Shaft Seal	1	27	07849-0100	Valve Seat	6
12A	04917	Ball Bearing	1	28	06809	Valve Plate	6
12B	01086	Ball Bearing	1	29	07906-0100	Valve Spring (except P221/P230-5111)	6
13	03026	Crankshaft (P217A-5100)	1	29	06816	Valve Spring (P221/P230-5111 only)	6
13	04920	Crankshaft (P218A-5100)	1	30	07907	Valve Spring Retainer	6
13	04921	Crankshaft (P219A-5100)	1	31	07853-0001	O-Ring	6
13	04919	Crankshaft (P220A-5100)	1	32	07928-0100	Plug	6
13	04922	Crankshaft (P221A-5100)	1	33	07913-0001	O-Ring	6
13	04918	Crankshaft (P230A-5100)	1	34	08316-0100	Hex Head Cap Screw	8
14	06207	Fitting Key	1	36	12138	Plug, 3/8" BSP	1
15	08333	Connecting Rod	3	36A	07109-0400	Plug, 1/2" BSP	1
16	08469-0100	Plunger Assembly	3				
16A	08468-0100	Plunger Base, 316 S.S.	3				
16B	08455	Plunger	3				
16C	08456-0100	Tension Screw, 316 S.S.	3				
16D	07204-0100	Crush Washer, 316 S.S.	3				
16E	07203	Support Ring	3				
16F	07023	O-Ring	3				

P200A-5100 SERIES REPAIR KITS

Plunger Packing Kits

P200A-5100 - #09756

Item	Part#	Description	Qty
21	08443	O-Ring	3
23	06704	Grooved Seal	3
23A	08087	Grooved Seal Ring	3
23B	06163	Drip Shield	3
24	07904	Pressure Ring	3

P200A-5111 - #09602-0011

Item	Part#	Description	Qty
21	08443-0001	O-Ring	3
23	08087-0010	Grooved Seal, Viton	6
23B	06163	Drip Shield	3
24	07904	Pressure Ring	3

Valve Assembly Kits

P200A-5100 - #09139-0011

P200A-5111 (except P221/P230-5111)

Item	Part#	Description	Qty
26A	03469	Valve Assembly	6
31	07853-0001	O-Ring	6
33	07913-0001	O-Ring	6

P221/P230-5111 - #09775

Item	Part#	Description	Qty
26A	04273	Valve Assembly	6
31	07853-0001	O-Ring	6
33	07913-0001	O-Ring	6

Oil Seal Kit

#09144

Item	Part#	Description	Qty
19	08356	Oil Seal	3