

Spare Parts List - LP301A-0081

ITEM	PART	DESCRIPTION	QTY	ITEM	PART	DESCRIPTION	QTY
1	07759	Crankcase	1	36	13238	Leakage Seal	3
2	13000	Oil Filler Plug Assy.	1	37	13240	Seal Case	3
3	05940	Cover Plate	1	38	07140	O-Ring, Seal Case	3
3A	07223-0100	Spring Ring	2	38A	13241	Support Ring for 38	3
3B	05051	Hexagon Screw	2	39	12055-0001	O-Ring	3
4	06085	Crankcase Cover	1	39A	07693	Support Ring for 39	3
5	07104	O-ring, Crankcase Cover	1	40	06083	V-Sleeve	3
6	05943	Oil Sight Glass w/Gasket	1	40A	13366	Pressure Ring	3
8	06086	Oil Dipstick Assy.	1	40B	13367	Guide Ring for 40	3
9	01009	O-Ring, (For Dipstick)	1	40C	06083A-0020	Sleeve, Teflon	3
10	01010	Cylinder Screw	4	41	07338	Pressure Spring	3
11	01011-0400	Spring Ring	5	43	13040	Valve Casing	1
12	07109	Plug, G1/2"	1	44A	07150-0001	O-Ring	9
13	07182	Gasket	1	44B	06266	Support Ring for O-Ring	3
14	07111	Bearing Cover	2	45	06078	Compression Spring	3
15	07112	Radial Shaft Seal	2	46	07060	Valve Assy., Complete	6
16	07113	O-Ring for Bearing Cover	2	46A	07064	Valve Seat	6
17	07114	Hexagon Screw	8	46B	07063	Valve Plate	6
20	07116	Taper Roller Bearing	2	46C	07062-0100	Valve Spring	6
20A	07117	Fitting Disc	1-3	46D	07066	Spacer Pipe	6
20B	13001	Fitting Disc	1-3	48	06077	Plug	3
21	05376	Shaft Protector	1	49	07157	Stud bolt	8
21A	05377	Shaft Guard Holder	1	49A	07158	Hexagon Nut	8
22	13242	Crankshaft	1	49B	07159	Disc	8
23	13243	Key	1	50	12250	Plug, G-1/2", S.S.	1
24	13340	Connecting Rod Assy.	3	50A	06807	Steel Ring	1
24A	13277	Inner Hex Screw	6	52	13020	Disc for Crankshaft	1
24B	13278	Spring Washer	6	53	06607	Hexagon Screw	1
25	13341	Crosshead Assy.	3	54	13044*	Plug, 1" BSP	2
28	13232	Crosshead Pin	3	55	13151*	Plug, 1-1/4" BSP	2
29A	07125	Centering Sleeve	3				
29B	07127	Plunger Pipe	3				
29C	13031	Tensioning Screw	3				
29D	07755	Copper Ring	3				
30	07779	Oil Scraper	3				
31	07133	Oil Seal	3				
35	13364	Seal Sleeve	3				

*BSP to NPT Adapters/Seals (sold separately)
 Inlet Port = 13377 (Adapter) / 13376 (Seal)
 Discharge Port = 13373* (Adapter) / 13372 (Seal)

* rated up to 3000 PSI. For higher pressure adapters, contact Giant.

Repair Kits

<p>Plunger Packing Kit # 09459-0081 For pumps manufactured on or after 4/96</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><u>Item</u></th> <th style="text-align: left;"><u>Part #</u></th> <th style="text-align: left;"><u>Description</u></th> <th style="text-align: right;"><u>Qty.</u></th> </tr> </thead> <tbody> <tr><td>36</td><td>13238</td><td>Leakage Seal</td><td style="text-align: right;">3</td></tr> <tr><td>38</td><td>07140-0001</td><td>O-Ring</td><td style="text-align: right;">3</td></tr> <tr><td>38A</td><td>13241</td><td>Support Ring</td><td style="text-align: right;">3</td></tr> <tr><td>39</td><td>12055-0001</td><td>O-Ring</td><td style="text-align: right;">3</td></tr> <tr><td>39A</td><td>07693</td><td>Support Ring</td><td style="text-align: right;">3</td></tr> <tr><td>40</td><td>06083</td><td>Sleeve, Nitrile</td><td style="text-align: right;">3</td></tr> <tr><td>40A</td><td>13366</td><td>Pressure Ring</td><td style="text-align: right;">3</td></tr> <tr><td>40C</td><td>06083-0020</td><td>Sleeve, Teflon</td><td style="text-align: right;">3</td></tr> </tbody> </table> <p>Oil Seal Kit # 09577</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><u>Item</u></th> <th style="text-align: left;"><u>Part #</u></th> <th style="text-align: left;"><u>Description</u></th> <th style="text-align: right;"><u>Qty.</u></th> </tr> </thead> <tbody> <tr><td>31</td><td>07133</td><td>Oil Seal</td><td style="text-align: right;">3</td></tr> </tbody> </table>	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	36	13238	Leakage Seal	3	38	07140-0001	O-Ring	3	38A	13241	Support Ring	3	39	12055-0001	O-Ring	3	39A	07693	Support Ring	3	40	06083	Sleeve, Nitrile	3	40A	13366	Pressure Ring	3	40C	06083-0020	Sleeve, Teflon	3	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	31	07133	Oil Seal	3	<p>Valve Kits # 09196-001</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><u>Item</u></th> <th style="text-align: left;"><u>Part #</u></th> <th style="text-align: left;"><u>Description</u></th> <th style="text-align: right;"><u>Qty.</u></th> </tr> </thead> <tbody> <tr><td>44A</td><td>07150-0001</td><td>O-Ring</td><td style="text-align: right;">6</td></tr> <tr><td>44B</td><td>06266</td><td>Support Ring</td><td style="text-align: right;">3</td></tr> <tr><td>46A</td><td>07064</td><td>Valve Seat</td><td style="text-align: right;">3</td></tr> <tr><td>46B</td><td>07063</td><td>Valve Plate</td><td style="text-align: right;">3</td></tr> <tr><td>46C</td><td>07062-0100</td><td>Valve Spring</td><td style="text-align: right;">3</td></tr> </tbody> </table> <p># 09196A-001</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><u>Item</u></th> <th style="text-align: left;"><u>Part #</u></th> <th style="text-align: left;"><u>Description</u></th> <th style="text-align: right;"><u>Qty.</u></th> </tr> </thead> <tbody> <tr><td>44A</td><td>07150-0001</td><td>O-Ring</td><td style="text-align: right;">9</td></tr> <tr><td>44B</td><td>06266</td><td>Support Ring</td><td style="text-align: right;">3</td></tr> <tr><td>46A</td><td>07064</td><td>Valve Seat</td><td style="text-align: right;">6</td></tr> <tr><td>46B</td><td>07063</td><td>Valve Plate</td><td style="text-align: right;">6</td></tr> <tr><td>46C</td><td>07062-0100</td><td>Valve Spring</td><td style="text-align: right;">6</td></tr> </tbody> </table>	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	44A	07150-0001	O-Ring	6	44B	06266	Support Ring	3	46A	07064	Valve Seat	3	46B	07063	Valve Plate	3	46C	07062-0100	Valve Spring	3	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	44A	07150-0001	O-Ring	9	44B	06266	Support Ring	3	46A	07064	Valve Seat	6	46B	07063	Valve Plate	6	46C	07062-0100	Valve Spring	6
<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>																																																																																										
36	13238	Leakage Seal	3																																																																																										
38	07140-0001	O-Ring	3																																																																																										
38A	13241	Support Ring	3																																																																																										
39	12055-0001	O-Ring	3																																																																																										
39A	07693	Support Ring	3																																																																																										
40	06083	Sleeve, Nitrile	3																																																																																										
40A	13366	Pressure Ring	3																																																																																										
40C	06083-0020	Sleeve, Teflon	3																																																																																										
<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>																																																																																										
31	07133	Oil Seal	3																																																																																										
<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>																																																																																										
44A	07150-0001	O-Ring	6																																																																																										
44B	06266	Support Ring	3																																																																																										
46A	07064	Valve Seat	3																																																																																										
46B	07063	Valve Plate	3																																																																																										
46C	07062-0100	Valve Spring	3																																																																																										
<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>																																																																																										
44A	07150-0001	O-Ring	9																																																																																										
44B	06266	Support Ring	3																																																																																										
46A	07064	Valve Seat	6																																																																																										
46B	07063	Valve Plate	6																																																																																										
46C	07062-0100	Valve Spring	6																																																																																										