

SPARE PARTS LIST - P540 and P541

<u>ITEM</u>	<u>PART</u>	<u>DESCRIPTION</u>	<u>QTY.</u>	<u>ITEM</u>	<u>PART</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	04405	Crankcase	1	21	06560	O-Ring	3
2	04234	Oil Dipstick Assembly	1	22	05308	Sleeve	6
3	04406	Crankcase Cover	1	23	04430	Grooved Ring	3
4	04407	O-Ring	1	23A	04431	Scraper	3
5	07109	Oil Drain Plug	1	24	04432	Sleeve Support Ring	3
5A	06015	Gasket for Oil Drain Plug	1	25	04433	Drip Return Ring	3
6	01010	Screw	4	26	04434	Valve Casing (P540)	1
6A	01011-0400	Spring Washer	4	26	04458	Valve Casing (P541)	1
7	04408	Bearing Cover	1	32	04435	Plug	6
7A	05943	Oil Sight Glass	1	33	12055	O-Ring	6
7D	03545	Bearing Cover	1	34	06494	Cap Screw	8
8A	04409	Shim	1-3	34A	04417	Cap	2
8B	04410	Shim	1	36	12249	Plug, 1" BSP	1
9	04411	O-Ring	2	36A	13372-0300	Copper Ring	1
10	13133	Screw with Washer	8	37	04436	Plug, 1-1/2" BSP	1
10A	06725	Spring Washer	8	46	04437	Inlet Valve Assembly	3
11	04238	Radial Shaft Seal	1	46A	13304	Valve Seat	3
12	04239	Tapered Roller Bearing	2	46B	12055	O-Ring	3
13	04425	Crankshaft	1	46C	13306	Valve Plate	3
14	04241	Fitting Key	1	46D	13307	Inlet Valve Spring	3
15	04242	Connecting Rod Assembly	3	46E	13308	Spring Tension Cap	3
16A	03542	Plunger Pipe	3	47	04438	Discharge Valve Assembly	3
16B	04865	Tension Screw	3	47A	13304	Valve Seat	3
16C	07023	O-Ring	3	47B	12055	O-Ring	3
16D	07203	Support Ring	3	47C	13306	Valve Plate	3
16E	07258	Steel Washer	3	47D	04439	Discharge Valve Spring	3
17	04412	Crosshead w/Plunger Base	3	47E	13308	Spring Tension Cap	3
17A	07124	Crosshead Pin	3		04400	Gear Assy. (1-19, 34)	
19	07624	Radial Shaft Seal	3		04441	Manifold Assy. (20-47 w/out 34)	
20	03533	Seal Retainer	3		04442	Manifold Assy. (20-47 w/out 34)	

REPAIR KITS - P540 and P541

Plunger Packing Kit - #09776

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
21	06560	O-Ring	3
22	05308	Sleeve	6
23	04430	Grooved Seal	3
23A	04431	Scraper	3

Inlet Valve Assembly Kit - #09777

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
33	12055	O-Ring	3
46	04437	Inlet Valve Assembly	3

Discharge Valve Assembly Kit - #09778

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
33	12055	O-Ring	3
47	04438	Valve Assembly	3

Oil Seal Kit - #09755

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
19	07624	Radial Shaft Seal	3