

CP420-5123 and CP425-5123 SPARE PARTS LIST

ITEM	PART	DESCRIPTION	QTY.	ITEM	PART	DESCRIPTION	QTY.
1	CP08377	Crankcase	1	16A	CP08384-0600	Plunger Base	3
2	CP08378	Oil Fill Plug with Gasket	1	16B	CP05960	Plunger Pipe	3
3	CP06479	Crankcase cover	1	16D	CP08399-0100	Tensioning Screw	3
3A	CP07186	Oil Sight Glass w/ Gasket	1	16E	CP07023-0001	O-Ring, EPDM	3
4	CP08380	O-Ring	1	16F	CP07203	Backup Ring	3
5	CP07109-0400	Oil Drain Plug	1	16G	CP07161-0100	Seal Ring	3
5A	CP06015	O-Ring	1	16H	CP06431	Flinger	3
5B	CP08092-0100	Plug with Gasket	1	17	CP06790	Crosshead Pin	3
6	CP08093	Screw	4	19	CP05444	Oil Seal	3
6A	CP01011-0400	Spring Washer	4	20	CP05443-0100	Seal Case	3
7	CP04739	Bearing Cover, Open	1	21	CP07266-0003	O-Ring, EPDM	3
8	CP05291	Bearing Cover, Closed	1	23	CP06144	V-Sleeve, Brown	3
8A	CP05292	Shim	1-3	23B	CP12255-0020	Weep Seal	3
8B	CP05293	Shim (May not be present)	1	24	CP08376	Pressure Ring	6
8C	CP05964	Shim (May not be present)	1-2	25	CP08394-0100	Weep Return Ring	3
9	CP01016	O-Ring	2	26	CP06255-5000	Manifold	1
10	CP07114-0100	Screw with Washer	8	27A	CP04643-0103	Valve Assembly	6
10A	CP01011-0400	Spring Washer	8	27	CP08370-0100	Valve Seat	6
11	CP07459	Radial Shaft Seal	1	28	CP06791-0100	Valve Plate	6
12	CP05350	Taper Roller Bearing	2	29	CP06377-0100	Valve Spring	6
13	CP04741	Crankshaft (CP420-5123)	1	30	CP08372	Valve Spring Retainer	6
13	CP04740	Crankshaft (CP425-5123)	1	31	CP07212-0003	O-Ring, EPDM	6
13A	CP04742	Spacer Ring	1	32	CP08373-0600	Plug	6
14	CP08091	Fitting Key	1	33	CP07214-0003	O-Ring, EPDM	6
15	CP08390	Connecting Rod Assembly	3	34	CP08396-0100	Hexagon Screw	8
15A	CP05349	Connecting Rod Screw	3	36	CP13150-0100	Plug, 3/4" BSP	1
15B	CP05348	Adapter Sleeve	3	36A	CP06808	Steel Ring	1
16	CP05351-0100C	Plunger Assembly, (items 16A-16H)	3	37	CP13321-0100	Plug, 1" BSP	1

CP420-5123 and CP425-5123 Repair Kits

Plunger Packing Kit # CP09595

Item	Part #	Description	Qty
21	CP07266-0003	O-Ring	3
23	CP06144	V-Sleeve	3
23B	CP12255-0020	Weep Seal	3
24	CP08376	Pressure Ring	6

Valve Assembly Kit # CP09596-0103

Item	Part #	Description	Qty.
27A	CP04643-0103	Valve Assembly, Complete	6
33	CP07214-0003	O-Ring	6

Oil Seal Kit

P400 Series - # CP09641

Item	Part #	Description	Qty
19	CP05444	Oil Seal	3

Preventative Maintenance Check-List & Recommended Spare Parts List						
Check	Daily	Weekly	50hrs	Every 500 hrs	Every 1500 hrs	Every 3000 hrs
Oil Level/Quality	X					
Oil Leaks	X					
Water Leaks	X					
Belts, Pulley		X				
Plumbing		X				
Recommended Spare Parts						
Oil Change (p/n 1154)			X	X		
Seal Spare Parts (1 kit/pump) (See this page for kit list)					X	
Oil Seal Kit (1 kit/pump) (See this page for kit list)					X	
Valve Spare Parts (1 kit/pump) (See this page for kit list)						X