

PARTS LIST - LP121-4000HT & LP121-4000HTC PUMPS

Item	Part	Description	Qty.	Item	Part	Description	Qty.
1	07759	Crankcase, LP121HT	1	31A	06118	Oil Seal	3
1	05198	Crankcase, LP121HTC	1	32	06116	Oil Seal Retainer	3
2	13000	Oil Filler Plug Assembly	1	32A	05596	O-Ring	3
3	05940	Cover Plate	1	33	06117	Compact Ring	3
3A	07223-0100	Spring Washer	2	35	07135	Seal Sleeve, LP121HT	3
3B	05051-0100	Hexagon Screw	2	35	03310	Seal Sleeve, LP121HTC	3
4	06085	Crankcase Cover	1	36	07137	Leakage Seal	3
5	07104	O-Ring	1	37	07139	Seal Case	3
6	07186	Oil Sight Glass Assembly	1	38	07140	O-Ring	6
8	06086	Oil Dipstick Assembly	1	39	07142-0100	Pressure Ring	3
9	01009	O-Ring	1	40	13199	V-Sleeve	6
10	01010-0100	Hexagon Socket Screw	4	41	07146-0100	Support Ring	3
11	01011-0400	Spring Washer	5	42	07147	Tension Spring	3
12	07109-0400	Oil Drain Plug	1	43	13018-5000	Valve Casing	1
13	06015	O-Ring	1	44A	07150	O-Ring	9
14	07111	Bearing Cover	2	44B	06266	Support Ring	3
15	07112	Crankshaft Seal	2	45	06078	Spring	3
16	07113	O-Ring	2	46	07060	Valve Assembly	6
17	07114-0100	Hexagon Screw	8	46A	07064	Valve Seat	6
20	07116	Taper Roller Bearing	2	46B	07063	Valve Plate	6
20A	07117	Shim, 0.1 mm	1-3	46C	07062-0100	Valve Spring	6
20B	13001	Shim, 0.15 mm	1-3	46D	07066	Spring Retainer	6
20C	04091	Shim, 0.2 mm	1-3	48	06077	Plug	3
21	05376	Shaft Protector	1	49	07157	Stud Bolt	8
21A	05377	Shaft Guard Holder	1	49A	07158	Nut	8
22	03367	Crankshaft	1	49B	07159	Washer	8
23	08091	Key	1	50	07423-0100	Plug, 1/4" BSP	1
24	13340	Connecting Rod Assembly	3	50A	07755-0100	Steel Ring, 1/4" BSP	1
25	13341	Crosshead Plunger	3	52	13020	Disc for Crankshaft	1
		Base Assembly	3	53	04561	Hexagon Screw	1
28	13232	Crosshead Pin	3	54	13044	Plug, 1" BSP	2
29A	07125	Sleeve	3	55	13322-0100	Plug, 1-1/2" BSP	2
29B	07130	Plunger Pipe	3	56	03311	Threaded Pipe, LP121HTC	3
29C	13031	Plunger Bolt	3	57	06588	Push-In Fitting, LP121HTC	6
29D	07161A-0100	Steel Ring	3	58	06587	Elbow	2
30	07779	Flinger	3				
31	06120	Seal Retainer, Complete (31A-33)	3				

LP121-4000HT(C) PUMP REPAIR KITS

Plunger Packing Kit #09310-0100

Item	Part No.	Description	Qty
36	07137	Leakage Seal	3
38	07140	O-Ring	6
39	07142-0100	Pressure Ring	3
40	13199	V-Sleeve	6

Valve Assembly Kit #09196A

Item	Part No.	Description	Qty
44A	07150	O-Ring	9
44B	06266	Support Ring	3
46A	07064	Valve Seat	6
46B	07063	Valve Plate	6
46C	07062-0100	Valve Spring	6

Oil Seal Kit #09571

Item	Part No.	Description	Qty
31A	06118	Oil Seal	3
32A	05596	O-Ring	3
33	06117	Compact Ring	3