

CLP121A/CLP121A-4000 Parts List

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
1	CP05198	Crankcase	1	29D	CP07755	Copper Ring (CLP121A)	3
2	CP05199	Oil filler Plug Assy.	1	29D	CP07161A-0100	Seal Ring (CLP121A-4000)	3
3	CP04802	Cover Plate	1	31	CP07133	Oil Seal	3
3A	CP04803	Spring Ring	2	35	CP05203	Seal Sleeve (CLP121A)	3
3B	CP04804	Hexagon Screw	2	35	CP05203-0100	Seal Sleeve (CLP121A-4000)	3
4	CP06085	Crankcase Cover	1	35A	CP05204	Retainer (CLP121A)	3
5	CP07104	O-ring, Crankcase Cover	1	35A	CP05203-0100	Pressure Ring (CLP121A-4000)	3
6	CP05943	Oil Sight Glass Assembly	1	36	CP13291-0020	Grooved Seal	3
7	CP04805	Cover Plate	1	37	CP07139	Seal Case	3
8	CP06086	Oil Dipstick Assy	1	38	CP07140-0003*	O-Ring	3
9	CP01009	O-Ring, Dipstick Assy.	1	39	CP05941	Pressure Ring	3
10	CP01010	Cylinder Screw (CLP121A)	4	40	CP06917	V-Sleeve	9
10	CP01010-0100	Cylinder Screw (CLP121A-4000)	5	40A	CP06916	V-Sleeve, Teflon	6
11	CP01011-0400	Spring Ring	5	41	CP06918	Support Ring	3
12	CP07109	Plug (CLP121A)	1	42	CP05942	Spacer Pipe	3
12	CP07109-0400	Plug (CLP121A-4000)	1	43	CP13029	Valve Casing (CLP121A)	1
13	CP06015	O-Ring	1	43	CP13018-0400	Valve Casing (CLP121A-4000)	1
14	CP07111	Bearing Cover	2	44A	CP07150-0003*	O-Ring	9
15	CP07112	Radial Shaft Seal	2	46	CP05205	Valve Assembly	6
16	CP07113	O-Ring	2	46A	CP07064	Valve Seat	6
17	CP07114	Hexagon Screw (CLP121A)	8	46B	CP07063	Valve Plate	6
17	CP07114-0100	Hexagon Screw (CLP121A-4000)	8	46C	CP07062-0100	Valve Spring	6
20	CP07116	Taper Roller Bearing	2	46D	CP07066	Spacer Pipe	6
20A	CP07117	Fitting Disc	1-3	48	CP07156	Plug	3
20B	CP13001	Fitting Disc	1-3	49	CP05206	Stud bolt	8
21	CP05376	Shaft Protector	1	49A	CP07158	Hexagon Nut	8
21A	CP05377	Shaft Guard Holder	1	49B	CP07159	Disc	8
22	CP13242	Crankshaft	1	50	CP07423	Plug (CLP121A)	1
23	CP13243	Fitting Key	1	50	CP07423-0100	Plug (CLP121A-4000)	1
24	CP13340	Connecting Rod Assy.	3	50A	CP07161	Copper Ring (CLP121A)	1
24A	CP13227	Hex Screw	3	50A	CP07755-0100	Steel Seal Ring (CLP121A-4000)	1
24B	CP13278	Spring Washer	3	52	CP13020	Disc for Crankshaft	1
25	CP13341	Crosshead / Plunger Assy.	3	53	CP04561	Hexagon Screw	1
28	CP13232	Crosshead Pin	3	54	CP13044	Plug, 1" BSP	1
29A	CP05200	Spacer Pipe	3	55	CP13322-0100	Plug 1-1/2" BSP	1
29B	CP07130	Plunger Pipe	3				
29C	CP05201	Tension Screw	3				

CLP121A Pump Repair Kits

Plunger Packing Kit - #09716

<u>Item</u>	<u>Part#</u>	<u>Description</u>	<u>Qty.</u>
36	CP13291-0020	Leakage Seal	3
38	CP07140-0003*	O-Ring	3
40	CP06917	V-Sleeve	9
40A	CP06916	V-Sleeve, Teflon	6

Valve Assembly Kit- #09608

<u>Item</u>	<u>Part#</u>	<u>Description</u>	<u>Qty.</u>
44A	CP07150-0003*	O-Ring	9
46A	CP07064	Valve Seat	6
46B	CP07063	Valve Plate	6
46C	CP07062-0100	Valve Spring	6
46D	CP07066	Spacer Pipe	6

Oil Seal Kit- #09577

<u>Item</u>	<u>Part#</u>	<u>Description</u>	<u>Qty.</u>
31	CP07133	Oil Seal	3

*NOTE: It is extremely important that these EPDM O-Rings do not come into contact with mineral oil or mineral grease. Use Silicone grease only.