

MP4120-SWS/MP4124-SWS PARTS LIST

<u>ITEM</u> <u>QTY.</u>	<u>PART #</u>	<u>DESCRIPTION</u>		<u>ITEM</u>	<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	06100	Crankcase	1	35B	13050	Rear Support Ring (MP4124)	3
2	13000	Oil Filler Cap Assembly	1	35C	13049	Rear V-Sleeve (MP4124)	3
4	07243	Cover, Crankcase	1	35D	07266	O-Ring for Seal Retainer	3
5	07244	O-Ring, Crankcase Cover	1	36	07267	Snap Ring	3
8	01008	Oil Dip Stick	1	39	07268	Pressure Ring (MP4120)	3
9	01009	O-Ring, Dip Stick	1	39	06082	Pressure Ring (MP4124)	3
10	01010	Screw, Crankcase Cover	4	40	07322	V-Sleeve (MP4120)	3
11	01011-0400	Spring Washer	4	40	06083	V-Sleeve (MP4124)	3
12	07109	Oil Drain Plug	1	41	07270	Support Ring (MP4120)	3
13	07182	Gasket, Oil Drain Plug	1	41	06084	Support Ring (MP4124)	3
14	07245	Bearing Cover	2	41A	07329	Spacer	3
15	07247	Seal, Crankshaft	2	42	07275	Tension Spring	3
16	07627	O-Ring, Bearing Cover	2	42A	06102	Tension Plug	3
17	07114	Hex Screw, Bearing Cover	9	42B	07332	O-Ring	3
20	07248	Roller Bearing, Tapered	2	43	06104	Manifold Head	1
20A	07249	Shim	2	44	07280	Valve Seat	6
20B	06962	Fitting Disc	2	44A	07281	O-Ring, Valve Seat	6
21	05375	Shaft Protector	1	45	07282	Valve Plate	6
22	07251	Crankshaft	1	46	07283	Discharge Valve Spring	3
23	07252	Key	1	46A	06959	Inlet Valve Spring	3
24	07253	Connecting Rod	3	47	07284	Spring Retainer, Discharge	3
25	07596	Crosshead Complete	3	48	06108	Plug, S.S.	3
28	07255	Crosshead Pin	3	48A	07332	O-Ring, Plug	3
29A	07256	Centering Sleeve	3	49	06109	Stud, Manifold	6
29B	07262	Ceramic Plunger (MP4120)	3	49A	07313	Shim, Stud	2
29B	13046	Ceramic Plunger (MP4124)	3	50	07158	Nut, Manifold Stud	6
29C	13007	Bolt, Sold only w/#07258	3	50A	07159	Spring Washer	6
29D	07258	Seal Washer	3	51	06110	Spacer	3
30	06136	Flinger	3	52	06111	Valve Housing	3
31	07260	Crankcase Oil Seal	3	53	12057	O-Ring	3
35A	07265A	Rear Seal Retainer (MP4120)	3	54	06115	Spring Retainer, Inlet	3
35A	04034	Rear Seal Retainer (MP4124)	3	57	13020	Disc for Crankshaft	1

MP4120-SWS/MP4124-SWS REPAIR KITS

Plunger Packing Kits

MP4120-SWS - #09044-SWS

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
35B	13050	Rear Support Ring	3
35C	13049	Rear V-Sleeve	3
35D	07266	Rear O-Ring	3
40	07322	V-Sleeve	3

MP4124-SWS- #09731

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
35B	13050	Rear Support Ring	3
35C	13049	Rear V-Sleeve	3
35D	07266	Rear O-Ring	3
40	06083	V-Sleeve	3

Inlet Valve Assembly Kit - # 09062

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
42B	07332	O-Ring Tension Plug	3
44	07280	Valve Seat	3
44A	07281	O-Ring, Valve-Seat	3
45	07282	Valve Plate	3
46A	06959	Valve Spring	3
53	12057	O-Ring	3
53A	12027	O-Ring	3
54	06115	Spring Retainer	3

Discharge Valve Assembly Kit - #09043

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty</u>
42B	07332	O-Ring, Tension Plug	3
44	07280	Valve Seat	3
44A	07281	O-Ring	3
45	07282	Valve Plate	3
46	07283	Valve Spring	3
47	07284	Spring Retainer	3