

LP122/LP123/LP255 PARTS LIST

A = LP122A

B = LP123

C = LP255

D=LP122B

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
1	07759	Crankcase	1	35	06699	Seal Sleeve (C)	3
2	13000	Oil Filler Plug	1	35A	07740	O-Ring	3
3	15940	Cover Plate (A)	1	35B	13141	O-Ring (C)	3
3A	07223-0100	Spring Washer (A)	2	36	13415	V-Sleeve, Weep (A, B)	3
3B	05051	Hexagon Screw (A)	1	36	13025	V-Sleeve, Weep (C)	3
4	06085	Crankcase Cover	1	36A	13416A	Pressure Ring, Weep, (A, B)	3
5	07104	O-Ring	1	36A	06700	Pressure Ring (C)	3
6	05943	Oil Sight Glass W/Gasket (A)	1	36B	06174	Drip Shield (A, B)	3
6	07186	Oil Sight Glass W/Gasket(B, C)	1	37	06701	Support Disc (C)	3
8	06086	Oil Dipstick	1	39	07744	Pressure Ring, (A, B)	3
9	01009	O-Ring	1	39	13026	Pressure Ring (C)	3
10	01010	Screw	4	40	07745	V-Sleeve (A, B)	6
11	01011-0400	Spring Washer, (A, B)	5	40	13027	V-Sleeve (C)	6
12	07109	Oil Drain Plug	1	41	07746	Support Ring, (A, B)	3
13	07182	Gasket	1	41	06702	Support Ring (C)	3
14	07111	Bearing Cover	2	41	07746-0100	Support Ring, SS (D)	
15	07112	Crankshaft Seal	2	43	13343	Valve Casing, (A)	1
16	07113	O-Ring	2	43	06703	Valve Casing, (B, C)	1
17	07114	Hex Screw	8	44	07748	Valve Seat	6
20	07116	Taper Roller Bearing	2	44A	07150	O-Ring	6
20A	07117	Fitting Disc, 0.1mm	1	45	07749	Valve Plate	6
20B	13001	Fitting Disc, 0.15mm	2	46	07750	Valve Spring	6
20C	04091	Shim	3	46A	07751	Valve Assy. Complete (#44, 44A, 45, 46, & 47)	6
21	05376	Shaft Protector	1	47	07752	Spring Retainer	6
21A	05377	Shaft Guard Holder	1	48	07753	Plug, (A)	6
22	13242	Crankshaft	1	48	06504	Plug, (B, C)	6
23	13243	Key	1	48	07753-0100	Plug, SS (D)	
24	13340	Connecting Rod Assy.	3	48A	12055	O-Ring	6
24A	13277	Hex Screw	6	49	07157	Stud Bolt	8
24B	13278	Spring Washer	6	49A	07158	Nut	8
25	13341	Crosshead Plunger Base Assy.	3	49B	07159	Washer	8
28	13232	Crosshead Pin	3	50	07423	Plug, (A, B, C)	1
29A	07735	Centering Sleeve	3	50A	07161	Gasket	1
29B	07736	Plunger Pipe (A, B)	3	52	13020	Disk for Crankshaft	1
29B	13022	Plunger Pipe (C)	3	53	06607	Hexagon Screw	1
29C	07737	Plunger Bolt	3	54	07756	Plug 1" NPT, (A)	1
29D	07755	Copper Gasket	3	54	06626	Plug 1" NPT, (B, C)	1
29E	06087	Spacer Pipe	3	55	07757	Plug 1-1/2" NPT, (A)	1
30	07779	Flinger	3	55	06627	Plug, 1-1/2" NPT, (B, C)	1
31	07133	Radial Shaft Seal	3				
35	13342	Seal Sleeve, (A, B)	3				

NOTE: For LP122 pumps manufactured prior to 5/94, which need weep seal replacement, change the pressure ring (36) to the newer style (p/n 13416) and use the new style weep seal (p/n 13415) in your pumps.

LP122/LP123/LP255 PUMP REPAIR KITS

Plunger Packing Kits

09477 (LP122, LP123)

(for pumps manufactured after 4/98)

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
35A	07740	O-ring	3
36	13415	V-Sleeve, Weep	3
40	07745	V-Sleeve	6

09535 (LP255)

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
35A	07740	O-ring	3
35B	13141	O-ring	3
36	13025	V-Sleeve weep	3
40	13027	V-Sleeve	6

Valve Assembly Kit - #09136

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
46A	07751	Valve Assembly, Complete	3
48A	12055	O-ring	3

Oil Seal Kit - #09577

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
31	07133	Radial Shaft Seal	3