

## GP7622 PARTS LIST

<u>ITEM</u>	<u>PART</u>	<u>DESCRIPTION</u>	<u>QTY.</u>	<u>ITEM</u>	<u>PART</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	05769	Crankcase	1	38A*	13286	O-Ring	3
1A	05525	Head for Oil Dipstick	1	38B*	07303	O-Ring	3
1B	01009	O-Ring	1	38C*	07332	O-Ring	6
2	13000	Oil Filler Plug Assembly	1	38D*	07683	Support Ring	6
4	07601	Crankcase Cover	1	39	03453	Seal Sleeve	2
5	05798	Seal for Crankcase Cover	1	39A	03454	Seal Sleeve, Middle	1
8	07603	Oil Dip Stick Assembly	1	39B	03455	Nozzle, Weep Return	1
9	01009	O-Ring, Dip Stick	1	39C**	03456	Tolerance Disc	1
10	22706	Hexagon Screw	8	39D	07204-0100	Seal Ring, Steel	6
11	06725	Spring Washer	8	40	07338	Tension Spring	3
12	07109	Drain Plug	8	41	06753	Support Disc	3
13	06272	Copper Seal Ring, 1/2"	8	42*	06754	Spiral Ring (Packing)	6
14	05770	Bearing Cover	2	43*	06755	Support Ring	6
14A	12204	O-Ring	8	44*	06756	Guide Ring	3
15	05771	Radial Shaft Seal	2	46*	13390	Seal Ring	3
16	05772	O-Ring for Bearing Cover	2	47	06758	Spacer Disc	3
17	05642	Hexagon Socket Screw	8	48*	05524	Circlip	3
18	05039	Spring Washer	8	49	03457	Stopper	3
19	03448	Spacer Disc	2	50*	05450	Valve Spring	3
20	03449	Taper Roller Bearing	2	51*	03458	Inlet Valve Plate	3
20A	04570	Shim, 0.15 mm	1-2	52	03459	Valve Body	3
20B	05794	Shim, 0.1 mm (may not be present)	1-5	53*	03460	Seal Edge Ring	3
21	05645	Shaft Guard Holder	1	54	03461	Valve Casing	1
21A	05646	Shaft Guard	1	55*	03462	Valve Spring Guide	3
22	03450	Crankshaft	1	56*	06959	Valve Spring, Heavy Duty	3
23	07614	Key	1	57*	03463	Discharge Valve Plate	3
24	05770	Connecting Rod Assembly	3	58	03464	Hexagon Socket Screw	8
25	05778	Crosshead Assembly	3	59	03465	Washer	8
28	05779	Crosshead Pin	3	60	04061	Plug, 1/2" BSP	2
30	03451	Cover Plate	1	61	12332	Copper Seal Ring	2
30A	07225-0100	Hexagon Screw	8	62	03466	Lens Seal	2
30B	13136	Grommet	4	63	05373	Plug, 1/2" BSP	1
30C	08280	Disc	8	64	12249	Plug, 1" BSP	1
30D	13154	Cover	1	65	13372-0300	Seal Ring, Copper	1
31	07623	Eye Bolt	1	66	13362	Disc for Crankshaft	1
32^	07624	Radial Shaft Seal	3	67	13358	Hexagon Screw	1
33	07626	Seal Retainer	3	69	03141	Connection Nipple	1
33A^	07627	O-Ring for Seal Retainer	3	70	06588	Straight Screw Joint	4
33B	07628	Circlip for Seal Retainer	3	71	06589	Hexagon Socket Plug, 1/8"	2
33C	07249	Fitting Disc	3	72	03467	U-Pipe for Rinsing Line	2
34	13137	Oil Scraper (Flinger)	3	*	09853	Seal Repair Kit	
36	06748	Plunger	3	+	09854	Valve Repair Kit	
38	03452	Seal Sleeve	3	^	09221	Oil Seal Kit	