

## Parts List - GP8076A

<u>Item</u>	<u>Part</u>	<u>Description</u>	<u>Qty</u>	<u>Item</u>	<u>Part</u>	<u>Description</u>	<u>Qty</u>
1	05380	Crankcase	1	38	03563	Seal Case	3
2	06893	Oil Filler Plug Assy. with Vent	1	38A	03564	O-Ring	6
5	22929	Copper Washer	2	39	03565	Seal Sleeve	3
6	12256	Plug	1	39A	05066	O-Ring	3
7	05656	Plug, 3/8" BSP	1	40	03566	Support Ring	6
8	05035	Oil Dipstick Assembly	1	41	03567	Guide Ring	6
9	01009	O-Ring	1	42	03568	Spiral Ring	6
12	07109	Plug, 1/2" BSP	2	45	03569	Pressure Spring	3
13	06272	Seal	2	49	05072	Stud Bolt	8
14	05036	Bearing Cover, Closed	1	49A	05073	Hexagon Nut	8
14A	03597	Bearing Cover, Open	1	50	03570	Valve Casing	1
15	05112	Radial Shaft Seal	1	50A	13162	Centering Stud	2
16	05037	O-Ring	2	50B	03511	Discharge Valve Casing	1
17	05038	Hexagon Socket Screw	16	51	03572	Valve Assembly (51A-51F)	6
18	05039	Spring Ring	16	51A	03573	Spring Tension Cap	6
21	05044	Tapered Roller Bearing	2	51B	03574	Valve Seat	6
21A	05042	Fitting Disc	1-5	51C	03575	Valve Plate	6
21B	05043	Fitting Disc	1-5	51D	06560	O-Ring	6
22	05299	Crankshaft	1	51E	05080	Valve Spring	6
23	05104	Fitting Key	1	51F	03434	O-Ring	6
24	05047	Connecting Rod Assembly	3	56	03576	Discharge Valve Adaptor	3
25	05048	Crosshead c/w Plunger	3	56A	04955	O-Ring	3
28	05049	Crosshead Pin	3	56B	13156	O-Ring	3
29	05051	Hexagon Screw	4	57	05086	Pressure Spring	3
30	05052	Cover Plate	1	57A	07210-0100	Pressure Spring	3
30A	07225-0100	Hexagon Screw	5	58	05087	Hexagon Socket Screw	12
30B	13136	Grommet	5	59	07109	Plug 1/2" BSP	2
30C	05053	Washer	9	59A	06272	Copper Seal	2
30D	05050	Splash Cover	1	60	13322	Plug 1-1/2" BSP	1
31	07623	Eye Bolt	3	61	05088	Plug 3" BSP	1
32	05058	Radial Shaft Seal	3	62	05302	Plug, 1/4" BSP	6
32A	03118	Scraper	3	62A	06934	Copper Seal	6
33	03119	Seal Retainer	3	66	03503	Disc for Crankshaft	1
33A	05056	O-Ring	3	67	13433	Hexagon Screw	1
33B	05054	Clip Ring	3	68	07662	Mounting Aid for Valve (not shown)	1
33C	05059	Fitting Disc	3	K2	05027	Seal for Gear Cover	1
34	03586	Oil Shield	3	K3	03622	Gear Cover	1
36A	04934	Plunger Pipe Cover	3	K5	22706	Hexagon Socket Screw	8
36B	03561	Plunger Pipe	3	K6	08041	Washer	8
36C	03621	Tension Screw	3	K8	06272	Copper Seal	4
36D	07665-0100	Steel Washer	3	K9	07109	Plug, 1/2" BSP	4
36E	06900	Centering Sleeve	3	K18	03623	Hexagon Socket Screw	4
36F	22704	O-Ring	3	K19	05053	Washer	4
36G	12092	O-Ring	3				

## Repair Kits - GP8076A

### Plunger Packing Kits - #09863A

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
38A	03564	O-Ring	6
39A	05066	O-Ring	3
40	03566	Support Ring	3
41	03567	Guide Ring	6
42	03568	Spiral Ring	6

### Valve Repair Kit - #09864A

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
51	03572	Valve Assembly	6
56A	04955	O-Ring	3
56B	13156	O-Ring	3

### Oil Seal Kit - #09584A

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
32	05058	Radial Shaft Seal	3
32A	03118	Scraper	3
33A	05056	O-Ring	3