

Part List - GP8065-5100

<u>Item</u>	<u>Part</u>	<u>Description</u>	<u>Qty</u>	<u>Item</u>	<u>Part</u>	<u>Description</u>	<u>Qty</u>
1	05380	Crankcase	1	42	06997	V Sleeve	9
2	06893	Oil Filler Plug Assy with Vent	1	43	05118-0100	Sleeve Support Ring	3
5	22929	Copper Washer	2	45	05119	Seal Tension Spring	3
6	04369	Plug, 3/8" BSP	1	49	05072	Stud Bolt	8
7	05656	Plug for oil dipstick	1	49A	03634	Hexagon Nut with Rim	8
8	05035*	Oil Dipstick Assembly	1	50	05074A-5000	Valve Casing	1
9	01009	O-Ring	1	50A	13162	Centering Stud	2
12	07109-0400	Plug 1/2" BSP	2	50B	05075-5000	Discharge Valve Casing	1
13	06272	Seal	2	51	05076-0100	Suction Valve Assembly	3
14	05036	Bearing Cover Closed	1	51A	04166	Spring Tension Cap	3
14A	05298	Bearing Cover Open	1	51B	05078-0100	Suction Valve Seat	3
15	05112	Radial Shaft Seal	1	51C	05079-0100	Valve Plate	3
16	05037	O-Ring	2	51D	07658-0001	O-Ring	3
17	05038	Hexagon Socket Screw	16	51E	05080	Valve Spring	3
18	05039	Spring Ring	16	52	05082-0100	Discharge Valve Assembly	3
21	05044	Tapered Roller Bearing	2	52A	04166	Spring Tension Cap	3
21A	05042	Fitting Disc	1-5	52B	05084-0100	Discharge Valve Seat	3
21B	05043	Fitting Disc	1-5	52C	05079-0100	Valve Plate	3
22	05299	Crankshaft	1	52D	05613	O-Ring	6
23	05300	Fitting Key	1	52E	05080	Valve Spring	3
24	05047	Connecting Rod Assembly	3	56	05085-0100	Discharge Valve Adaptor	3
25	05048	Crosshead c/w Plunger	3	56A	05613	O-Ring	3
28	05049	Crosshead Pin	3	57	05086	Pressure Spring	3
29	05051	Hexagon Screw	4	57A	07210-0100	Pressure Spring	3
29A	05381	Bracket 1 for Cooling Hose	2	58	05087-0100	Hexagon Socket Screw	12
29B	05383	Bracket 2 for Cooling Hose	2	59	07109-0400	Plug 1/2" BSP	1
30	05052	Cover Plate	1	59A	06807	Steel Seal	1
30A	07225-0100	Hexagon Screw	5	60	13151-0100	Plug 1-1/4" BSP	1
30B	13136	Grommet	5	61	05088-0100	Plug 3" BSP	1
30C	08280	Washer	9	64	03635	Adapter, 3/4" BSP to 1/2" BSP	2
30D	05050	Splash Cover	1	66	05303	Disc for Crankshaft	1
31	07623	Eye Bolt	3	67	13433	Hexagon Screw	1
32	05058	Radial Shaft Seal	3	68	04785	Push-In Fitting	7
32A	03118	Scraper	3	69	03440	Elbow Straight Screw Fitting	1
33	03119	Seal Retainer	3	72	03636	Hose	1
33A	05056	O-Ring	3	73	03442	Spiral Hose	1
33B	05054	Clip Ring	3	78	03790-0100	Oil Cooler Assembly (K1-K18)	1
33C	05059	Fitting Disc	3	K1	03705	Cooling Vane Plate	1
34	05060	Oil Shield	3	K2	03791	Seal for Gear Cover	1
36A	05063-0100	Cover for Plunger Pipe	3	K3	03792	Gear Cover	1
36B	05115	Plunger Pipe	3	K4	03710	Clamping Screw	2
36C	03621	Tension Screw	3	K5	22706	Hexagon Socket Screw	8
36D	07665-0100	Steel Washer	3	K6	06725	Washer	8
36E	06900	Centering Sleeve	3	K7	05030	Connection for Oil Cooler	1
36F	05615	O-Ring	3	K8	06807	Steel Ring	5
36G	02026-0001	O-Ring	3	K9	07109-0400	Plug 1/2" BSP	1
37	03630	Seal Retainer	3	K10	05031-0100	Connecting Branch	1
37A	05619	O-Ring	3	K11	05032-0100	Hose Adaptor	2
37B	03631	Support Ring	3	K12	05033	Hose for Cooler	2
37C	03632	Scraper	3	K13	05402-0100	Hose Clamp	4
38	05064-0100	Seal Case	3	K14	05403	Hose Guard	2
38A	06667-0001	O-Ring	6	K15	05404-0100	Hose Coupling Nut	2
39	05116-0100	Seal Sleeve	3	K16	03793	Elbow, 90° for Hose	2
39A	05066	O-Ring	3	K17	03706	Hose Plate for Oil Cooler	1
40	03633	Grooved Seal	3	K18	03707-0100	Reducing Nipple	2
41	05117-0100	Pressure Ring	3				

GP8065-5100 PUMP REPAIR KITS

Plunger Packing Kit - #09586-0100

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
37A	05619	O-Ring	3
38A	06667-0001	O-Ring	6
39A	05066	O-Ring	3
40	03633	Grooved Seal	3
42	06997	V-Sleeve	9

Inlet Valve Kit - #09587-0100

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
51	05076-0100	Inlet Valve Assembly	3
56A	05613	O-Ring	3

Oil Seal Kit - #09584A

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
32	05058	Radial Shaft Seal	3
32A	03118	Scraper	3
33A	05056	O-Ring	3

Discharge Valve Kit - #09588-0100

<u>Item</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
52	05082-0100	Discharge Valve Assembly	3
56A	05613	O-Ring	3