

GP7128-4100 PARTS LIST

ITEM	PART	DESCRIPTION	QTY.	ITEM	PART	DESCRIPTION	QTY.
1	05769	Crankcase	1	39D	03787	Support Disc	3
1A	05525	Head for Oil Dipstick	1	40	05442	Guide Ring	3
1B	01009	O-Ring, Dipstick	1	40A	05441	Pressure Ring	3
2	13000	Oil Filler Plug Assembly	1	41	05440	Support Ring	6
4	07601	Crankcase Cover	1	42	05439	Spiral Ring	6
5	05798	Seal for Cover	1	43	03788	Spacer Disc	3
8	07603	Oil Dip Stick Assembly	1	45	07173	Tension Spring	3
9	01009	O-Ring, Dip Stick	1	49	13159	Stud Bolt	8
10	22706	Inner Hexagon Screw	8	49A	06958	Hexagon Nut	8
11	06725	Spring Washer	8	50	03628	Valve Casing	1
12	07109-0400	Drain Plug	6	50A	13162	Cylinder Stud	2
13	06272	Copper Seal	6	51	04727	Inlet Valve Assembly (51B-F)	3
14	05770	Bearing Cover	2	51B	05193	O-Ring	3
14A	12204	O-Ring	8	51C	04725	Inlet Valve Seat	3
15	05771	Radial Shaft Seal	2	51D	13130	Valve Plate	3
16	05772	O-Ring, Bearing cover	2	51E	07062-0100	Valve Spring	3
17	05642	Inner Hexagon Screw	8	51F	13147	Spacer Pipe	3
18	05039	Spring Washer	8	52	04728	Discharge Valve Assembly (52B-F)	3
20	05773	Taper Roller Bearing	2	52B	05193	O-Ring	3
20A	05774	Fitting Disc (Shim)	1-8	52C	04726	Discharge Valve Seat	3
20B	04570	Fitting Disc (Shim)	1	52D	13130	Valve Plate	3
21	05645	Holder for Shaft Protector	1	52E	07062-0100	Valve Spring	3
21A	05646	Shaft Protector	1	52F	13147	Spacer Pipe	3
22	05575	Crankshaft	1	56	03439	Plug, 1/2" BSP-1/8" BSP	1
23	07614	Key	1	57	04695	Plate Spring Retainer	3
24	05777	Connecting Rod Assembly	3	57A	04698	Plate Spring	18
25	05778	Crosshead Assembly	3	57B	07853	O-Ring	3
28	05779	Crosshead Pin	3	58	03788	Plug	3
30	05713	Cover Plate	1	58A	07700-0001	O-Ring, Viton	3
30A	05051-0100	Hexagon Screw	8	58B	07693	Support Ring	3
30C	08280	Disc	8	58C	07702	Hexagon Screw	12
30D	05714	Cover	1	59	07109-0400	Plug, 1/2" BSP	4
31	07623	Eye Bolt	1	59A	06807	Ring	4
32	07624	Radial Shaft Seal	3	60	13150-0100	Plug, 3/4" BSP	1
33	06950	Seal Retainer	3	61	13151	Plug, 1-1/4" BSP	1
33A	07627	O-Ring for 33	3	66	13362	Disc for Crankshaft	1
33B	06951	Circlip for 33	3	67	13358	Hexagon Screw	1
33C	07249	Shim	3	68	04785	Connector	4
34	13137	Flinger	3	70	03440	L-Joint	4
36	06427	Plunger	3	72	03441	Hose	1
38	05354	Seal Case	3	73	03442	Spiral Hose	2
38A	06577	O-Ring, Seal Case	3		07662	Tool for valve assembly	
38B	07693	Support Ring for 38A	3		17212	Crankcase Assembly (1-34/49/49A/50A/66/67)	
38C	06736	O-Ring for 39	3		04671	Manifold Assembly (50-61 w/out 50A)	
38D	12056	Support Ring for 38C	3		03046	Plunger Replacement Kit (36-45)	
39	03784	Seal Sleeve	3				
39A	03785	Grooved Ring	3				
39B	03786	Flinger	3				
39C	06584	Clip Ring	3				

GP7128-4100 Pump Repair Kits

Plunger Packing Kit - 09464A

Item	Part #	Description	Qty.
38A	06577	O-Ring, Seal Case	3
38B	07693	Support Ring	3
38C	06736	O-Ring	3
38D	12056	Support Ring	3
39A	03785	Grooved Ring	3
39B	03786	Flinger	3
39C	06584	Clip Ring	3
40	05442	Guide Ring	3
41	05440	Support Ring	6
42	05439	Spiral Ring	6

Valve Assembly Kit - #09520A

Item	Part #	Description	Qty.
51B	05193	O-Ring	3
51C	04725	Inlet Valve Seat	3
51D	13130	Valve Plate	3
51E	07062-0100	Valve Spring	3
52B	05193	O-Ring	3
52C	04726	Discharge Valve Seat	3
52D	13130	Valve Plate	3
52E	07062-0100	Valve Spring	3
58A	07700-0001	O-Ring, Viton	3
58B	07693	Support Ring	3

Oil Seal Kit # 09221

Item	Part #	Description	Qty.
32	07624	Radial Shaft Seal	3
33A	07627	O-Ring	3